

# How to Install ArtWool

Install ArtWool insulation in just 3 easy steps:

1. **Insert**
2. **Compress**
3. **Release**

ArtWool insulation **cuts quickly and accurately** with a knife for a **fitting around pipes, electrical boxes, wiring, ductwork, and between structural members.**

## **To do the work:**

Wear long sleeved, **loose fitting clothing, gloves, eye protection, knee pads** and a **dust mask**. Tools needed:

- Tape measure
- Long serrated bread knife
- Straight edge
- Staple gun (When acoustical and or vapor barrier/retarder is required)
- Caulking gun/Acoustical sealant
- Acoustical and or vapor barrier/retarder if required